Serial number location

Every unit has a SN number label, you could track back the unit's record based on the SN number. The SN number label is as below:



1. Split, Ceiling floor and Portable units

The SN number label is located on the right side on the unit, below the nameplate.





2. Air handler

The SN number label is normally located on the front panel, next or below the nameplate.



3. Cassette

The SN number label is normally located on the side panel, next or below the nameplate.



4. Outdoor unit

The SN number label is located on the right side of sidedischarge outdoor unit, below the name plate.



The SN number label is located on the front panel of topdischarge outdoor unit, below the nameplate.

